

## Additional Installation Tips: Versa Guard Wall Protection

The following is intended to provide the installer with information to be used in addition to the comprehensive application instructions printed on the bellyband found on each roll of wallcovering.

It is very important that the information contained on the bellyband be read and understood before considering the following additional application instructions.

- ✓ It is very important to select the proper primer and adhesive before attempting an installation of Type III wallcovering. A heavy-duty strippable clay adhesive at full strength and acrylic primer/sizer is recommended for optimal results.
- ✓ Pasting the wall is *not* recommended. The adhesive should be applied to the back of the material with a roller or pasting machine and booked according to the adhesive manufacturer instructions.
- ✓ In order to maintain high quality seam finishes it is recommended that a very sharp high-quality blade is used when installing the material.
- ✓ Inside and outside corners may require the application of heat via a heat gun to achieve the best result. An even layer of adhesive applied to the wall at the corners with a four-inch brush may also be needed in addition to the adhesive used on the wallcovering in order achieve the optimum finish result.

